

# | *activetrax*<sup>TM</sup> |

self-powered audio



Thank you for purchasing activetrax<sup>TM</sup>, on the go audio<sup>TM</sup>, from Seattle Sports Company. This manual contains important safety information, as well as easy to follow instructions. Please read through carefully in order to receive the maximum benefits from your new purchase.

For future reference, please enter your serial number here:

---



# WARNING

**Ignoring Safety warnings could result in injury or death!**

Read these instructions. Keep them though the life of your activetrax™.

**Heed all warnings and follow all instructions.**

- Do not expose activetrax™ to dripping or splashing liquid or set objects filled with liquid on activetrax™.
- Protect cords or cables from being walked on or pinched; particularly at plug-in points and where they exit from the apparatus.
- Do not use during lightning storms..



# CAUTION

There are no user serviceable parts inside activetrax™. Refer all service problems to a qualified service professional. Service is required when activetrax™ is damaged in any way, including being dropped in water, exposed to extreme heat, had liquid spilled on it, been dropped or had objects dropped on it, or in any way does not operate as normal.

- Do not use activetrax™ near water or extreme humidity.
- Do not set near any heat sources such as radiators, heat registers, stoves, camp fires, or other apparatus that produce heat. Only use attachments or accessories specified by the manufacturer.
- Avoid placing this unit in places exposed to heat radiating items (such as electric heaters) or on top of other stereo equipment that radiate heat. Avoid places lacking in ventilation, areas that are dusty, locations subject to constant vibration, or any places with excessive humidity.
- Operate as described in this manual.
- Upon completion of service or repair, ask the service tech to perform safety checks.

**NOTE:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to activetrax™. Such modifications could void the user's authority to operate activetrax™.

- If activetrax™ becomes dusty, wipe exterior with a soft dust cloth. Never use dusting sprays or polishes.
- If activetrax™ becomes dirty, wipe with a soft, cloth that is **slightly damp** with mild soap and water. **Never** allow liquid to get inside activetrax™. activetrax™ is designed to operate on normal 120V 60Hz AC power. Do not attempt to operate activetrax™ on other power sources. Operating activetrax™ on other power sources may cause damage and is not covered by your warranty.

## charging information

RUNS FOR 7 HOURS WITH FULL  
BATTERY CHARGE

5 Hours of solar power provides  
at least 30 minutes of play time  
(average volume)

20 minutes of radio or iPod®  
speaker play with 1 minute of  
cranking.



To Full Charge via crank – 40  
minutes (assuming 3 revolutions/  
second)

To Full Charge via solar power – 35  
hours (assuming solar energy at  
600 w/m<sup>2</sup>)

## radio operation

Turn radio on by rotating volume control clockwise. There should be a noticeable click.

To turn off, simply rotate the volume control counterclockwise until the click is heard again.



red light in grill indicates  
radio signal strength

Slide the Band Selector Switch to the desired band. There should be a noticeable click with each band. The center bump may not match up with the text and should not be a cause of concern.

Tune to your desired station by rotating the tuning dial.

Adjust the volume control as desired.

## weather band operation

activetrax™ receives continuous U.S. Government weather broadcasts from the National Oceanic and Atmospheric Administration (NOAA.) NOAA sends out weather reports from over 750 stations, covering all 50 states, Puerto Rico, Virgin Islands, and all U.S. Pacific Territories; including coastal waters. These broadcasts are transmitted on seven bands from 162.400 MHz to 162.550 MHz.

**Note:** The NOAA weather band frequency operates in a range that is sometimes prone to interference by more powerful TV broadcasts. To receive a weather band broadcast you may need to move the antenna to minimize interference by TV broadcasts in the same range. You may also find it helpful to push down the antenna to its closed position.

National Weather broadcasts are generally lower volume broadcasts. You may need to adjust the volume of activetrax™ to comfortably hear weather band broadcasts.

## stereo to mono signal information

The cord included with the activetrax™ **does not** combine the stereo sound to mono. Stereo sound is combined to mono on the circuit board.

## **fcc information**

activetrax™ has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. activetrax™ generates, uses, and can radiate radio frequency energy. If not used in accordance with the instructions it may cause harmful interference to radio communications.

There is no guarantee that interference will not occur.

If activetrax™ does cause harmful interference to radio or television reception (which can be determined by turning it off and on), you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Contact a professional TV/radio technician for help.
- Connect the equipment into an outlet on a circuit different from what activetrax™ is using.

activetrax™ complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

## limited warranty

### One year guarantee

Seattle Sports Company products are guaranteed for workmanship and materials for one year. Should this product fail during its warranty period, Seattle Sports will repair or replace the product at their discretion, after product inspection.

Please write Seattle Sports Company for a return authorization at 3217 W. Smith St. #1, Seattle, WA 98199.

This warranty is void with commercial use. In no event should the Seattle Sports Company be liable for incidental or consequential damages. iPod® is a registered trademark of Apple.

This warranty gives you specific legal rights. You may have other rights, which vary from state to state.

© 2008 Seattle Sports Company

## other seattle sports products

Hydrostar™ S.U.B.  
Submersible  
Utility Beam



LEDHedz™  
MicroLamp



Nightquest LED  
Deck Compass

