



# THREE ROLL CLOSURE VERTICAL INSTRUCTIONS



**FILL TO ABOUT HERE**

### Stuff Goes In!


The first step with any dry bag is loading your stuff into it.

Closing the bag requires rolling the top edge downward. Three or more rolls provide an ideal seal for splashproof protection, so make sure to leave enough room.

### Roll it

Fold the top over once where the buckles create an edge. Squeeze any extra air out of the bag.

Maintaining the single fold, continue to roll closed a minimum of three times.




### WARNING

Dry bags are superior protection, but this bag is not suitable for protection from submersion.

Dry bags are designed to provide enhanced protection from rain and temporary contact with water.

### Buckle it

Your bag cinches down over the top.



### SEATTLE SPORTS COMPANY

3217 W Smith St. #1

Seattle, WA. 98199

© 2011 Seattle Sports Co.

### WARRANTY

Seattle Sports Company are guaranteed for materials and workmanship for one year. Normal wear and tear or damage from misuse, accident or alterations are not covered. Use of this product in a professional setting is not covered. Seattle Sports assumes no liability for incidental damages or

injuries resulting from the use or misuse of this product. You may have additional warranties or limitations outlined in product packaging. Not intended for storage of optical, photographic or electrical equipment.